



INSTALLATION MANUAL


DUAL-AIR[®]




X 1




X 1




X 2




X 16 / 20 / 24 / 28




X 16 / 20 / 24 / 28





X 6



X 6 / 8 / 10 / 12




1




2


2.1






2.2




2.3




3





4




4.1




4.2




5




6.1




6.2




6.3




6.4




6.5







6.6




6.7




7



CAM	ELECTRIC WIRE	WIRE COLOR	FUNCTION
C1	F1 n.c.	White	Opening
C2	F2 n.c.	Brown	Closing



C1



C2

